

Labycare-Heavy Duty Conveyorised Bag Closing Machine (SKSS-PMHE2071)

Heavy Duty Conveyorised Bag Closing Machine

Description :

A **Heavy Duty Conveyorised Bag Closing Machine** is designed for **automatic stitching and sealing of filled bags** in packaging lines. The system consists of a **belt conveyor and high-speed bag stitching machine**, which moves the filled bags to the sewing head for secure closure. It is widely used in **seed processing plants, grain storage units, fertilizer industries, and food processing industries** for efficient and continuous bag sealing.

<u>Specifications :</u>	Stitching Capacity	600 + bags per hour
	Electric Motor	0.5 HP, 3 Phase-1440 rpm
	Mechanical Trimming Knives	Installed in the sewer head which cut the thread after a bag is stitched.
	MOUNTING COLUMN Material of Construction Movement	Rigid M.S. Seamless tubes. Up and Down movement is obtained with the help of lead screw and bevel gears.
	Belt width	300mm
	Conveyor length	3000 mm
	Carrying capacity	600+bags per hour, which is synchronised with the speed of the Sewer Head.
	Electric Motor	1 HP, 3 Phase
	Speed reduction	With help of Gear Box

labycare

www.labycare.com | Email: labycare@gmail.com