

Labycare-Grader (With Built In Destoner & Aspirator) (Product Cat # SKSS-G2078)



Grader (with Built-In Destoner and Aspirator) manufacturer by Labycare

Description :

The Destoner is suitable for removing stones and other impurities from a variety of millets, including Little Millet, Kodo Millet, Barnyard Millet, Proso Millet, Finger Millet, Foxtail Millet, and others.

A separate grading unit is attached for size-wise classification, ensuring better separation and uniformity. Additionally, an aspirator is integrated to remove lightweight impurities such as husk and dust.

<u>Specifications :</u>	Capacity	Up to 250 kg/hour
	Structure	Heavy structure makes the machine sturdy and more stable. Deck mounted on foundation frame for stability of machine.
	Feeding System	Provided with feed hopper, regulator for in flow of grain across the entire width of deck.
	Separation	Fitted with five stage cleaning facility.
	Motor	3 HP motor of reputed make to run on 415v, 50Hz, 3phase AC supply.
	Operation	Vibratory system with aspiration

	and size grading system to separate the finer impurities also.
Working	Continuous type.
Vibratory Deck	Vibratory deck with well balanced built in fan for air volume adjustment for accurate final separation of grains by counter current.
Deck Inclination	Facility for independent alteration for inclination of desk (lateral & longitudinal).
Accessories	One set of removable screens

labycare

www.labycare.com | Email: labycare@gmail.com