

Labycare-Multi Grain Cleaner / Winnower / Power Duster (Product Cat # SKSS-MDM2079)



Multi Grain Cleaner / Winnower / Power Duster manufacturer by Labycare

Description :

During the pre-cleaning stage in grain warehouses and rice mills, this equipment utilizes a double-sieve system for effective screening. A winnowing fan removes impurities such as sand, chaff, dust, dead insects, weevils, and other light contaminants from the grain.

Widely used in Indian grain markets—especially for cleaning wheat and paddy—this equipment is specifically designed to clean a variety of cereals, grains, pulses, and seeds from different crops with precision and efficiency.

Specifications :

- Roller feeder in feed hopper for uniform feeding of seeds/grains on screen.
- Screen cleaning system for efficient grading of seeds/grains.
- Capacity depending upon the raw material (2TPH – 5TPH).

- 16 to 18 gauge sheets thickness.
- Blower easy to open to fix any problem quickly
- Sieve set standard for paddy, wheat, mustard, soyabean, pulses and all other grains.
- Power operated by single phase motor (1.5 or 2HP).
- Sizes 42" X 50" (W x H)

labycare

www.labycare.com | Email: labycare@gmail.com