

Labycare-SEED GRADER/PADDY CLEANER (SKSS-SLE2052)



SEED GRADER/PADDY CLEANER Manufacturer by LABYCARE

Description :

A **Seed Grader / Paddy Cleaner** is a machine used for sorting and cleaning paddy seeds to ensure high-quality production. It removes impurities, such as dust, stones, and broken grains, using a combination of vibration and sieving. This enhances the purity of seeds and ensures uniform size for better germination.

<u>Specifications :</u> Suitability	: For all cereal grains, pulses, oil seeds, vegetable seeds etc.
Feed rate & blower speed	: Adjustable.
Screen layers	: Two screen system.
Operation	: By electricity & by hand.
Construction	: Made of teak wood & teak ply.
Motor	: Single phase electric motor 0.5 HP

Documents : <images/23e249947f8527d134eddb7afa467149.png>

labycare

www.labycare.com | Email: labycare@gmail.com