

## Labycare-DESTONER (SKSS-SLE2060)



Destoner Manufacturer by LABYCARE

### **Description :**

A Destoner is a grain cleaning machine used to remove stones, sand, and heavy impurities from seeds, cereals, and pulses. It works on the principle of density difference using vibration and airflow. Destoners are widely used in seed testing laboratories, food processing units, and agricultural industries for efficient cleaning.

<b><u>Specifications :</u></b>	Capacity (wheat basis)	2 Ton/hr	4-5 Ton/hr	7-8 Ton/hr
Screen Width	950mm	1050mm	1200mm	
Vibro Motors	0.5HP- 2No.	0.5HP- 2No.	0.5HP- 2No.	
Blower	7.5HP	12.5HP	15HP	
Accessories	Cyclone	Cyclone	Cyclone	

---

labycare

www.labycare.com | Email: labycare@gmail.com