

## Labycare-MAGNETIC DESTONER (SKSS-SLE2061)



MAGNETIC DESTONER Manufacturer by LABYCARE

### **Description :**

A Magnetic Destoner is a seed and grain cleaning device designed to remove stones, metal particles, and heavy impurities from cereals, pulses, and seeds. It uses strong magnetic force combined with gravity separation to ensure efficient cleaning. Commonly used in seed testing laboratories, flour mills, and food processing industries.

<b><u>Specifications :</u></b>	Roller Size	100mm x 850mm (Single Roller Magnetic Destoner)
	Magnet Type	Nd-FeB Rare Earth Magnet
	Magnet Grade	N-52
	Magnetic Strength	12,000 Gauss
	Body Material	Mild Steel (MS)
	Contact Parts	Stainless Steel (SS)
	Magnetic Roller	1 Unit
	Non-Magnetic Roller	1 Unit
	Belt	1000mm x 850mm x 0.7mm
	Gear Motor	1 HP
	Vibrator Motor	0.5 HP.

---

labycare

www.labycare.com | Email: labycare@gmail.com