

Labycare-AUTOMATIC WEIGHING & BAGGING MACHINE VIBRATORY FEEDER 1-5KG (SKSS-PMHE2068)



Automatic Weighing & Bagging Machine Vibratory Feeder 1-5kg Manufacturer by LABYCARE

Description :

The grain or seed material is first lifted by bucket elevators and loaded into the main storage bin. The elevator is driven by a motor mounted on the top platform, and a ladder is provided for safe access to the upper section for inspection and maintenance of components such as the fine/coarse cylinder, feed control system, and weighing bin.

<u>Specifications :</u>	Weighing Range	1kg to 5Kg
	Accuracy	± 0.5%
	Display	7 Segment, 7 Digit LED display, Digit height 25mm.
	Output Speed	4-5 bags per min. (No. of bags/min depends upon the commodity being weighed, weight of bag and accuracy required)
	Feeding system	Vibratory feeder (no need for compressed air).
	Bag type	Open mouth bags.
	Power Consumption	600 watts only.
	UPS	1 KVA (Machine can run on UPS for 30 min incase of power failure)

labycare

www.labycare.com | Email: labycare@gmail.com