

Labycare-Automatic Weighing & Bagging Machine10-50kg Pneumatic Type (SKSS-PMHE2070)



Automatic Weighing & Bagging Machine10-50kg Pneumatic Type Manufacturer by LABYCARE

Description :

To ensure precise and effective packaging, a pneumatic automatic weighing bagging machine employs compressed air to power a number of components for bag filling and weighing. The bag is pneumatically clamped, material is fed into a weighing hopper, and the material is subsequently discharged into the bag in accordance with predetermined weight targets.

Specifications :	Weighing Range	10-50 kg
	Accuracy	± 0.5%
	Display	7 Segments, 7 Digit LED Display, Digit height 25 mm
	Output Speed	3 – 5 bags per min. (No. of bags per min depend upon the commodity being weighed, weight of bag and accuracy required).
	Bag type	Open Mouth type. Stitchable jute and gunny bags HDPE wooven bags
	Bag Holder	Pneumatic bag holder
	Compressed air requirement	6 Bar

labycare

www.labycare.com | Email: labycare@gmail.com