

Labycare-Ice flake machine (SKSS500)



Flake Ice Machine manufacturer by

Labycare

in India.

It is widely used in supermarket preservation, seafood restaurant, food processing, fruit and vegetable preservation, make the seafood, fresh meat and meat products more fresh.

Description :

Labycare Flake Ice Machine is dry and supercooled small ice in flat pieces with an irregular wafer shape. This type of small ice is produced by spraying or pouring water onto a cooled surface, usually in the form of a cylinder or drum. Water freezes on the surface and forms thin ice sheets.

Specifications :

- Power (W): 1.2 kw
 - Ice Shape: Flake Ice
 - Dimension (L*W*H): 760*730*450 mm
 - Origin: India
 - Brand Name: Labycare
 - Voltage: 220V/50HZ
 - Weight: 150 kg
 - Cooling way: Air Cooling
 - Material: Carbon Steel
 - Total Power: 1.76 kw
 - Capacity: 0.2-10T/24hr, 200kg/24hr
 - After sales Service: Engineers available to service machinery overseas
-

labycare

www.labycare.com | Email: labycare@gmail.com